



DISC SLIM


REF: K51700.SR



INSTALLATION INSTRUCTIONS



V.01



^K51700.01	^K51700.02	^K51700.03	□K51700.04	*K51700.05	□K51700.06	*K51700.07
<p>1 </p> <p>2 </p> <p>3 </p> <p>4 CONNECTION</p> <p></p> <p>ON-OFF: L, N, SEC+, SEC- PUSH1: L, N, PUSH, SEC+, SEC- DALI: L, N, DA1, DA2, SEC- 1-10V: L, N, 1-10V, SEC+, SEC- PUSH2: L, N, PUSH, DA/N, DA/L, SEC+, SEC- PHASE CUT: DIMMER, L, N, SEC+, SEC-</p> <p>*Models 05 and 07 don't work with PHASE CUT ^Models 01, 02 and 03 works with DIMMABLE REMOTE DRIVER □Model 04 and 06 works with PC REMOTE DRIVER</p> <p>5 </p> <p>6 </p> <p>7 </p>						

